



# Concerto Earphones

With charging case



## Included Contents:

- 1 Pair of Wireless Earbuds
- 1 Rechargeable Charging Case
- 1 Micro-USB to USB-A Charging Cable - 18 in.
- 3 Sizes of Silicone Ear Pads




SMALL

MEDIUM

LARGE

## General Functions:



## Operating Functions:


**Pairing Device (1st Way):** Remove both Earbuds from charging case and they will automatically start searching for a connection from a wireless enabled device. Connect to "CONCERTO-KINGTECH" in your device's wireless settings and a voice prompt will announce "connected."

**Pairing Device (2nd Way):** Press and hold the Function Control Button on both earbuds until they start blinking Blue & Red. They will automatically pair with each other, once successfully linked, connect to "CONCERTO-KINGTECH" in your device's wireless settings and a voice prompt will announce "connected."

**Playing Audio:** Use your connected wireless device to select and start playing music and audio. Click the Function Control Button once to Pause or Play track and click the button twice to skip to the next track.

**Calling:** Answer and End incoming calls by pressing the Function Control Button once.

**Turning Off:** Press and hold Function Control Button on either earbud until a voice prompt announces "turning off." This will automatically turn off both earbuds and disconnect from your device.



## Charging:

**Earbuds:** Place both earbuds in their respective ports in the Charging Case. If Charging Case is charged, LEDs on the front of the case and earbuds will light up and automatically start charging earbuds. Press the center button on Charging Case to stop charging and turn off to save battery life or if both Charging Case and Earbuds are charged.

**Charging Case:** Insert Micro-USB connector into port on the rear side of Charging Case and insert USB-A end connector into a power source, such as a USB-A port wall or car charger. All four LEDs will light up once Charging Case is fully charged. Each LED indicates 25%, 50%, 75%, and 100% charged.

## Attention:

- WARNING:** To prevent fire or shock hazards, do not expose this unit to rain or moisture.
- Keep your ears safe! To avoid hearing damage, make sure that the volume on your device is turned down before connecting your earbuds. After placing earbuds in/on your ears, gradually turn up the volume until you reach a comfortable listening level.
- To lengthen life of battery, fully charge at least once a month.
- Lithium batteries, like all rechargeable batteries, are recyclable and should be recycled or disposed of according to state and local guidelines. They should never be disposed of in normal household waste, and they should never be incinerated, as they might explode. Contact your local government for disposal or recycling practices in your area.

## Product Specifications:

- Wireless Connection Range: Up to 33 ft.
- Driver Unit: 10mm
- Frequency Response: 20hz - 20khz
- Speaker Resistance:  $32\Omega \pm 15\%$
- Speaker Sensitivity:  $95 \pm 5\text{dB}$
- Mic Sensitivity:  $-43 \pm 3\text{dB}$
- Earbud Battery: 40mAh Li-poly
  - Listening/Call Time: Up to 6 Hours
  - Stand-By Time: About 180 Hours
  - Charging Time: About 2 Hours
- Charging Case Battery: 300 mAh Li-poly
  - Can charge earbuds up to 3 times on a full charge
  - Rated Input Power: 10mW

MADE IN CHINA

KEY:

CUT (DO NOT PRINT)

FOLD (DO NOT PRINT)

BLACK & WHITE